


SL-ZAP-01
Artikel: 1030166

de Originalbetriebsanleitung
en Original instruction
fr Notice originale
nl Oorspronkelijke
gebruiksaanwijzing
it Istruzioni originali
es Manual original
pt Manual original




fi Alkuperäiset ohjeet
no Original bruksanvisning
da Original brugsanvisning
pl Instrukcja oryginalna
hu Eredeti használati utasítás
sv Bruksanvisning i original



DIN EN 60903
(VDE 0682-311)




AC 1000V/15
IEC 60900





Md = 1,2 Nm



Angabe Drehmoment lt. Zählerhersteller
bzw. Klemmenangabe max. Md = 2 Nm
Torque information according to the meter manufacturer
or terminal specification max. Md = 2 Nm




TX25




Angabe Drehmoment lt. Zählerhersteller max. Md = 2 Nm
Torque information according to the meter manufacturer
max. Md = 2 Nm



Variante für Klemmenmontage (Kippschutz):
Variant for clamp mounting (Anti-tip protection):



Variante für maximalen Verstellbereich:
Variant for maximum adjustment range:



Mittelmarkierung:
Center mark:

